

# **Sunrise**

## DECT Phone

user manual

Dear customer,

You have just acquired a DECT phone and we thank you for your custom.

This product follows a strategy of continuous development. We reserve the right to make changes without notice, modifications and improvements to the products described in this user manual.

To operate the device safely and easily, please read carefully the paragraph **"Recommendations and safety instructions"**, page 2.

 The CE label confirms that the product complies with the 1999/5/EC regulations of the European Union Parliament regarding wireless systems and telecommunications.

The declaration of compliance may be looked up on the **<http://support.sagemcom.com>** website or can be obtained from the following address:

**Sagemcom Broadband SAS**


250, route de l'Empereur

92848 Rueil-Malmaison Cedex - France

# Recommendations and safety instructions



For safety reasons, never put the handset in the base station without the battery inserted or without the lid on the battery compartment as this could cause an electric shock. To avoid damaging your handset/base, only use certified rechargeable batteries NiMH 1.2 V 800 mAh. Insert the batteries in the handset/base battery compartment respecting polarity.



Only use the power unit supplied and connect it to the electricity mains in accordance with the installation instructions in this user manual and the details on the sticker regarding voltage, electrical current and frequency. As a precaution if there is a risk of danger, the power plug can be pulled out to disconnect the 230 volt power supply. Therefore the sockets should be near the device and easily accessible.




Do not install your DECT telephone in a damp environment, such as a bathroom, washroom, kitchen etc, and not within 1.50 metres of a source of water or outside. This device is designed for use in temperatures of between 5 °C and 40 °C.



In zones where there is a risk of frequent thunder storms, we recommend that you protect your telephone line using an electric power surge protection device.



Do not attempt to remove screws or open the appliance. It does not contain any user-replaceable parts.



Your DECT telephone has a range of approx. 50 metres indoors and up to 300 metres outdoors. The range can be affected by the proximity of metal objects, such as a television and electrical devices.

Zones without reception may appear owing to elements in the building. This can cause brief interruptions in the conversation, caused by faulty transmission.



Certain medical equipment and highly-sensitive machines or security systems may be affected by the transmission power of the telephone. In these cases we recommend adhering to the safety information.



The used battery must be disposed of in line with the recycling regulations in this user manual.



# Index

## **Recommendations and safety instructions ..... 2**

## **Discover... ..... 8**

Browsing principle ..... 8

Charging ..... 9

Replacing the batteries ..... 10

Update phone software ..... 10

Menu tree structure ..... 11

## **Call..... 13**

Making a call..... 13

Receiving a call..... 13

Choose your line ..... 14

Put a call on hold ..... 14

Managing several calls..... 14

Receiving a second call..... 14

Switching from one call to the other ..... 15

Ending one of the calls in progress..... 15

Talking with two contacts at the same time (3-way conference) ..... 15

Making a second call ..... 16

Transferring calls..... 17

Options during a call .....	18
Enable/Disable loudspeaker (handsfree mode) .....	18
Adjusting volume .....	18
Enable the mute mode .....	18
Using additional handsets .....	19
Calling another handset (intercom) .....	19
<b>Manage your contacts... ..</b>	<b>20</b>
Add a contact .....	20
Call the contact .....	20
Edit a contact .....	21
Deleting an entry .....	21
Search for an entry .....	21
Delete all the entries .....	21
Speed dialling .....	22
<b>Voicemail... ..</b>	<b>23</b>
Call Voicemail .....	23
Modifying the Voicemail number .....	23
<b>Audio adjustment... ..</b>	<b>24</b>
Changing the ringing tone .....	24
Enabling/Disabling the silent mode .....	24
Enabling/Disabling audio alerts .....	25

## **Setting up... 26**

### **The phone... 26**

Setting the date and the time .....	26
Picking up and hanging up calls automatically.....	26
Changing the display language .....	27
Adjust the brightness .....	27
Update soft.....	27

### **The handset ..... 28**

Associate a new handset.....	28
Handset version .....	28
Resetting the handset .....	28

### **The base ..... 29**

Changing the base code .....	29
Resetting the base .....	29
Base version.....	29

### **The line ..... 30**

Change the line name.....	30
Pair the handset with a line.....	30
Call forwarding.....	31
Mask the line number .....	32
Manage several calls .....	32
Allow three-way communication (Intrusion) .....	32

### **Call management..... 33**

Managing your calls.....	33
--------------------------	----

### **The list of handsets ..... 33**

Manage handsets .....	33
-----------------------	----

## **Enjoy... 34**

### **Programming the alarm..... 34**

### **Program the timer ..... 34**

## **Tracing your calls... .....35**

Displaying the list of all calls ..... 35

Viewing the received or outgoing call list..... 36

Consulting the missed call log ..... 36

Managing the list of calls..... 37

The events log..... 37

Checking new events..... 37

## **Environnement.....38**

Packaging ..... 38




Batteries..... 38







The product ..... 38



# Discover...


## Browsing principle

To browse through menus, use the browser keys  and the Keys  and :

- Press **Menu** .
- OR
- Press the top ▲ or the bottom ▼ of the browser .
- Press the top ▲ or the bottom ▼ of the browser  to access the desired function.
- Validate your choice / Enter the menu by pressing the key .
- Cancel your choice / Exit the displayed menu:
  - either by pressing the  key: return to previous menu.
  - or by pressing the  key: the home screen is displayed.


### DETAILED BROWSER EXAMPLE: ACCESS TO THE CONTEXT MENU

During a call:





- Press the **Options**  key, **Second call** is displayed.
- Scroll through the options using the top ▲ or the bottom ▼ of the browser.
- Validate your choice by pressing the **Select** key.

# Charging

To charge your telephone, place the handset on its charger and make sure the charger is connected to the power supply.


The battery charging icon  moves to inform you that charging is in progress.

The icon display stops moving when the batteries are charged.


status	Description
	Batteries charged.
	Batteries are moderately charged.
	Batteries are low
	Batteries completely discharged

To ensure optimum charging, leave the handset on the base for at least **15 hours** when using the phone for the first time. During charging, the batteries may heat up. This is quite normal and perfectly safer.  
When the batteries are low, the handset emits a beep.

Switch the handset off and then on again

To turn off the handset, hold down the red key , the "**Power off ?**" message is displayed on the screen.

Press **Yes** to confirm.

To turn on your handset, press the red key  briefly, the "**Sunrise**" message is displayed on the screen.

# Replacing the batteries

- Turn off the handset. Turn it around so that the battery compartment is accessible.
- Remove the battery compartment hatch.
- Remove the old batteries, insert the new batteries one by one in compliance with the polarity of the batteries.
- Refit the battery compartment hatch.

Worn out batteries must be discarded, in accordance with the recycling instructions in chapter "Recommendations and safety instructions", page 2.

**To avoid damaging your handset, only use certified rechargeable AAA batteries NiMH 1.2 V 800 mAh, never use non rechargeable batteries.**

## Update phone software

The updated operation allows you to have new features in your phone or to have an optimized software.

This is done manually. To do this, plan a monthly upgrade search.

You can update the software version of your phone from the menu **Settings > Settings > Update Soft.**

# Menu tree structure

## Contacts

	List
	Search
	Add
	Delete all
	Speed Dialing

## Voicemail

--	--

## Options

During a call

	Second call
	Intercom
	Calls
	Contacts
	Selec. call line
	Mute
	Put on hold

## Calls

	All calls
	Incoming calls
	Outgoings calls
	Missed calls
	Events

## Audio

	External ringtone
	Internal ringtone
	Beeps
	Silent

## Services




	Alarm
	Timer

## Settings



Settings		Date/time
		Auto hang/pick up
		Language
		Brightness
		Update Soft
Adv. settings	Set handset	Registration
		Country
		Handset Version
		Reset handset
	Set base	Change code
		Reset base
		Base Version
	Set line	Line name
		Attached HS
		Call forward
		Configuration
	Selec. call line	
	Handset list	

# Call...

## Making a call

- Dial your contact's number.
- Press the key 
- OR -
- Press on the green key  for a longer time (more than 2 seconds).
- Dial your contact's number.
- At the end of the call, press the handset  key and place the handset back on its charger.




## Receiving a call

- To take a call press the  key or simply pick the handset up from its base if the automatic pick up option is activated.
- At the end of the call, press the handset  key and put the handset back on its charger. A sound signal is emitted.

To stop the handset ringing when an incoming call is received, press **Dismiss** .


# Choose your line

This menu allows you to select the line on which you want to make a second outgoing call (subject to service availability).

- During a call, press **Options** .
- Select **Selec. call line** and press **Select**.
- Select your line using the keys  or .
- Press **Select**. The action is confirmed by the indication "**Select**".

## Put a call on hold

### Options > Put on hold

During a call, press **Options** . Select **Put on hold** and press **Select**.

To take the call back, press **Options** . Select **Resume** and press **Select**.

## Managing several calls

Your phone allows you to take and manage several calls (subject to service availability) when you are already on the line.

### Receiving a second call

During a call, a beep indicates the arrival of a second call.

The contact details of the second caller are displayed on the screen.

**Case 1:** take the new call and put the current call on hold.

Press the  key.

The first caller is put on hold, you can speak with the new caller.

**Case 2 :** take the new call and end the current call.


Press **Replace**.

The call with your first caller is ended. You can speak with the new caller.

To reject all calls, press **Release**.

## Switching from one call to the other

**Options > Switch** (or )

During the call press  the current call is put on hold and you take the call that was previously on hold.

## Ending one of the calls in progress

**Options > Release**

During the call press **Options**. Choose the option **Release** using the ▲ or ▼ keys. Press **Select**.

The current call is ended and you resume the previous call.

During the call you can hang up both calls by pressing the  key for a long time.

A short press on the red  key ends the current call.

## Talking with two contacts at the same time (3-way conference)

**Options > Conference**


- During a double call, press **Options**. Choose the option **Conference** using the ▲ or ▼ keys. Press **Select**.
- You can then talk with the 2 contacts at the same time and " **Conference** " is displayed on the screen
- To end the conference call, replace the handset.

The 3-way conference is supported by the HD phone, subject to service availability.



# Making a second call

## Options > Second call

Select the number for the person you want to call in the address book by pressing , and then **Select**.

- OR -


Dial the number using the keypad and validate.


The second called number appears on the screen.

**A:** the order of the current call / double call.

**B:** the number and/or name of the call on hold.

**C:** the call duration.



You can also select the number of the person you are calling from your address book by pressing . For more details please refer to section "Search for an entry", page 21.

You can also make a second call by pressing on the  key.

## Transferring calls


During a call, you can transfer it to another handset. This function can be used as soon as your installation has two handsets registered on the same base.

A transfer to an inside contact is also supported by the HD phone, subject to service availability.

### UNANNOUNCED TRANSFER



This function allows you to transfer the current call directly to another device.

#### Options > Intercom

Steps	Calling handset	Called handset
1	Press <b>Select</b> .	
2	Select the handset (or all handsets) to call.	
3	Press <b>Call</b> .	
4		Rings: internal call.
5	Press <b>Options</b>  .	
6	Select <b>Transfert</b> and Press <b>Select</b> .	
7		Rings: external call. Take the call.
8	Hangs up automatically.	

### ANNOUNCED TRANSFER

This function allows you to transfer the current call to another device once it has been picked up.

Steps	Calling handset	Called handset
1	Press <b>Selcet</b> .	
2	Select the handset (or all handsets) to call.	
3	Press <b>Call</b> .	
4		Rings: internal call.
5		Press the  key to accept the internal call.
6	The external call is put on hold.	
7	Press <b>Options</b>  .	
8	Select <b>Transfert</b> and Press <b>Select</b> .	
9	Hangs up automatically. The external call is transferred.	
10		Call with the external caller.



Call...

# Options during a call

You can use the following options during a call:

## Enable/Disable loudspeaker (handsfree mode)



### HANDSET LOUDSPEAKER

During the call you can activate the handsfree mode by pressing the  key. The icon  is displayed on the screen.

To disable the hands-free mode, press the  key again. The icon  disappears.

When your battery charging icon displays the minimum, the handsfree mode is unavailable until the next charging cycle. The handsfree mode is optimised for speaking at 50 cm from the handset.



## Adjusting volume

During a call you can increase or lower the volume of the handset by pressing the  or  keys on the browser.


A bar graph makes it possible to adjust the volume according to 5 levels.

## Enable the mute mode

During a call, you can switch to mute mode and your handset's microphone will be muted and your contact will no longer hear you.

- During a conversation, press **Options**, press **Mute** . The icon  is displayed at the top of the screen.

### TO DISABLE THE MUTE MODE:

- Press **Unmute** .
- Your contact will hear you again.

You can also enable/disable the mute mode by pressing **Mute / Unmute** during a call.

## KEYBOARD SHORTCUT:




During a conversation, press and hold the  key to enable/disable the mute mode.

## Using additional handsets

You can associate additional handsets with your phone: you can then make and receive outside calls or calls between these handsets.

You first have to pair the handsets with the base.  
For further details, refer to the section “Associate a new handset”, page 28.

## Calling another handset (intercom)

- Press  key.
- Select the handset (or all handsets) you want to call.
- Press **Call**. The selected handset rings.
- Take the call from the handset by pressing .
- End the call by pressing .

# Manage your contacts...

The phonebook entries are managed by your Intenet Box.

Your phonebook is common to all the DECT handsets recorded on the same Intenet Box.

Your phone book contains up to 255 contacts

You can also directly access the list of phonebook entries using the  key.

When browsing through the phonebook, the handset displays the number of the current entry and the total number of available entries.

## Add a contact

### Menu > Contacts > Add

Specify the required information by confirming at each step:

- **Family name:** enter your contact's name,
- **First name:** enter your contact's first name,
- **Number:** enter the phone number(s) in the corresponding box (Work, Mobile).
- Select the ring tone of your choice from 14 different ring tones using the keys **Previous** or **Next** to identify the person calling you more easily.  
Press ▼ .
- Press **Store**.

To enter a text, press and hold the required key until the letter is displayed on the screen.

To insert a special characters, press the  key and use the ▲ or ▼ keys and the keypad numbers. Then confirm your selection by pressing **OK**.  
(Example: "<" = 2 times on ▼ and once on the keypad number 5).

## Call the contact

### Menu > Contacts

- Select a contact using **List** or **Search** menu and press **Select**.
- Select **Call** using the ▲ or ▼ keys and press **Select**.

# Edit a contact

## Menu > Contacts

- Select a contact using **List** or **Search** menu and press **Select**.
- Select **Edit** using the ▲ or ▼ keys and press **Select**.
- Change the name, first name and/or phone number by deleting characters using the **Clear** key and/or the ring tone and press ▼.
- Press **Store**.

# Deleting an entry

## Menu > Contacts

- Select a contact using **List** or **Search** menu and press **Select**.
- Select **Delete** and press **Select**.
- On the question **Delete ?**, press **Yes** to confirm the deletion of the entry.

# Search for an entry

## Menu > Contacts

- Select **Search** and press **Select**.
- On request **Family name**, enter the first letter of the name, the entire name, or part of the name and press **Select**.

# Delete all the entries

## Menu > Contacts

- Press **Select**.
- Select **Delete all** and press **Select**.
- On the question **Delete all ?**, press **Yes** to confirm the deletion of the all the entries.

**This operation will erase all the files in your Internet Box. Once this is done, you will have no more contact in each of your phones registered on your Internet Box.**


# Speed dialling

This function allows you to assign a keyboard shortcut to a contact in your phonebook.

You voice mail number is assigned to the key .

To call your contact, press and hold the key assigned to the number and the number is automatically dialled.

## Menu > Contacts


- Press **Select**.
- Select **Speed Dialing** and press **Select**.
- Select, using the key ▲ or ▼, the number of the keyboard key you want to assign to your contact (0~9).
- Press **Edit** .
- Select **Edit** and press **Select**
- Press **Contacts**, select the contact you want to assign a keypad shortcut.
- Press **Select**.  
You can also directly enter the number of your choice.
- Once the number is entered, press **Select**.
- To exit the menu, press **Back** 3 times in succession.

# Voicemail...

## Call Voicemail

When the answering machine of your Internet Box is deactivated, incoming calls in your absence are redirected to your telephone line's voice mail.

### Menu > Voicemail

- Select the line using the ▲ or ▼ key.
- Press **Call** .  
The service number in question is dialed automatically.

You can press and hold the key  to access your voice mail.

## Modifying the Voicemail number

### Menu > Contacts > Speed Dialing

The voicemail number is assigned to the key . To change it, see paragraph “**Speed dialling**”, page 22.



# Audio adjustment...

## Changing the ringing tone

You can change the ringing tone of:



- outside calls,
- calls between handsets (intercom).

### Menu > Audio

- Press **Select**.
- Select **External ringtone** to change the ringing tone for external calls.
- OR -
- Select **Internal ringtone** to change the ringing tone for internal calls.
- Scroll through the pre-recorded ringing tones using the ▲ or ▼ keys and press **Select**.
- Adjust the ring tone volume and press **Select**.

## Enabling/Disabling the silent mode

When in silent mode, the telephone ringer and keypad beeps are inhibited.

The browser  key can also be used to enable/disable the silent mode. When you have activated silent mode, your handset is silent for all functions of the alarm clock, timer type. If the silent mode is active the  icon is displayed.

### Menu > Audio

- Press **Select**.
- Select **Silent** to change the silent mode, then press **Select**.
- The message "**Activate silent mode ?**" is displayed on the screen.
  - Press **Yes** to confirm the enabling of the silent mode.
  - Press **No** to cancel the enabling of the silent mode.





# Enabling/Disabling audio alerts

Audio alerts apply to:

- pressing the keypad keys,
- putting the handset on the charger,
- low battery alert,
- others (error alerts).

The enabled function is marked by the symbol .

## Menu > Audio


- Press **Select**.
- Select **Beeps** to change the audio alerts, then press **Select**.
- Select **Keypad** and press **On/Off**  to enable or disable the keypad beeps.
- OR -
- Select **Charger** and press **On/Off**  to enable or disable the beep when the handset is placed on the charger.
- OR -
- Select **Battery low** and press **On/Off**  to enable or disable the low battery warning.
- OR -
- Select **Others** and press **On/Off**  to enable or disable the action not allowed warning.

# Setting up...

## The phone

### Setting the date and the time

**Menu > Settings > Settings**


- Select **Date/time** using the ▲ or ▼ keys and press **Select**.
- The date and time setting screen is displayed, press **Edit**.
- Set the clock mode (automatic or manual) by pressing **On/Off** . Press **Select**.
- Enter the date using alphanumeric keypad (the day, the month, then years) in DD/MM/YY format. Press **Select**.
- Enter the time using alphanumeric keypad (hours, then minute) in hh: mm format. Press **Select**.
- The message "**Save changes ?**" is displayed. Press **Store**.

If the automatic clock mode is enabled, it is not possible to change the date and time displayed on the handset.

### Picking up and hanging up calls automatically

This function allows you to take and end a call by simply taking the handset off or placing it back on its charger.

**Menu > Settings > Settings**

- Select **Auto hang/pick up** using the ▲ or ▼ keys and press **Select**.
- Select **Auto hangup** or **Auto pickup** using the ▲ or ▼ keys.
- Set the status (enabled or disabled) by pressing **On/Off** .
- Select "**Save changes ?**", confirm by pressing **Select**. The action is validated by the "**Select**" indication.

## Changing the display language

**Menu > Settings > Settings**

- Press **Select**.
- Select **Settings** using the ▲ or ▼ keys and press **Select**.
- Select **Language** using the ▲ or ▼ keys and press **Select**.
- Select the language to be used with the keys ▲ or ▼ and press **Select**.

## Adjust the brightness

**Menu > Settings > Settings**

- Select **Brightness** using the ▲ or ▼ keys and press **Select**.
- A bar graph is used to adjust the brightness according to 6 levels.
- Select the level you want using the keys ▲ or ▼.  
The brightness is directly visible on the screen.
- Press **Select**.

## Update soft

**Menu > Settings > Settings**

- Select **Update Soft** using the ▲ or ▼ keys and press **Select**.
- Press **Yes** to confirm.

# The handset

## Associate a new handset

**Menu > Settings > Settings > Set handset**

### From the handset:

- Select **Association** using the ▲ or ▼ keys and press **Select**.
- The message "**Press DECT button on Modem**" is displayed.
- Press **OK**.

### From the Internet Box:

Press and hold the "DECT" button (on the Internet Box) until the DECT indicator flashes quickly.

### From the handset:

- Once the Internet Box is detected, its name is displayed on the handset screen.
- Press **Select** to confirm.
- Once the handset is registered, the handset automatically exits the registration mode.

If the pairing operation fails, the message "Registration fail" appears on the screen.

## Handset version

**Menu > Settings > Adv. settings > Set handset**

- Select **Handset Version** using the ▲ or ▼ keys and press **Select**.  
The software and EEPROM version of the D49 handset is displayed on the screen.

## Resetting the handset

When you reset your handset, all the settings are returned to their initial values (factory settings), except for the phonebook.

**Menu > Settings > Adv. settings > Set handset**

- Select **Reset handset** using the ▲ or ▼ keys and press **Select**.
- On a confirmation request "**Reset handset ?**", press **Yes**.

Setting up...

# The base

## Changing the base code

The base code (PIN number) is 0000 as default and can be changed to 4 other numbers. You will be prompted to enter it, for example, when registering a new handset.

**Menu > Settings > Adv. settings > Set base**

- Select **Set base** using the ▲ or ▼ keys and press **Select**.
- Select **Change code** using the ▲ or ▼ keys and press **Select**.
- At the "**Old code**" prompt, enter the old 4-digit code and then confirm by pressing **Select**.
- At the "**New code**" prompt, enter the new 4-digit code and then confirm by pressing **Select**.
- At the "**Confirm le code**" prompt, enter the new code again and then confirm by pressing **Select**.

## Resetting the base

When you reset your base, all the settings are returned to their initial values (factory settings), except for the phonebook.

**Menu > Settings > Adv. settings > Set base**

- Select **Reset base** using the ▲ or ▼ keys and press **Select**.
- On a confirmation request "**Base reset?**", press **Yes**.

## Base version

**Menu > Settings > Adv. settings > Set base**

- Select **Base Version** using the ▲ or ▼ keys and press **Select**.
- The following information is displayed:
  - base software version,
  - EEPROM version,
  - base hardware version.

# The line

This menu allows you to change the settings of the lines on the base.

## Change the line name

**Menu > Settings > Adv. settings > Set line**


- Select **Line name** using the ▲ or ▼ keys and press **Select**.
- Press **Edit** to change the line name using the alphanumeric keys.
- Enter your line name by successively pressing the corresponding keys, press **Select**.

## Pair the handset with a line

This menu allows you to display the list of handsets paired with the line used.

The enabled function is marked by the symbol .

**Menu > Settings > Adv. settings > Set line**

- Select **Attached HS** using the ▲ or ▼ keys and press **Select**.
- Enter the base code and press **Select**.
- The list of paired handsets is displayed on the screen.
- Select the desired handset using the keys ▲ or ▼.
- Press **On/Off**  to pair/unpair the handset with/from the line used (the paired handset is then unpaired and vice versa).
- Press **Store**.

# Call forwarding

This function allows you to transfer all incoming calls if your phone is busy, if you do not answer the call or if you want to forward calls automatically to another number.

**Menu > Settings > Adv. settings > Set line**

- Select **Call forward** using the ▲ or ▼ keys and press **Select**.
- Select one of the three available options and confirm by pressing **Select**.

**On busy:** the call will be forwarded if the line is busy

- Select **Call forward** and press **Select**.
- Change the forwarding status and press **Select**.
- Select **Number** and press **Select**.
- Enter the number you want the call to be forwarded to and press **Select**.

**No answer:** the call will be forwarded if no answered within a time to be defined (in seconds)

- Select **Call forward** and press **Select**.
- Change the forwarding status and press **Select**.
- Select **Number** and press **Select**,
- Enter the number you want the call to be forwarded to and press **Select**.
- Select **Duration (sec)** and press **Select**.
- Enter the time in seconds before the call is transferred and press **Select**.

**Always:** the call is forwarded in all cases

- Select **Call forward** and press **Select**.
- Change the forwarding status and press **Select**.
- Select **Number** and press **Select**,
- Enter the number you want the call to be forwarded to and press **Select**.



## Mask the line number

This function, when enabled, hides your line number.

The enabled function is marked by the symbol .

### Menu > Settings > Adv. settings > Set line

- Select **Configuration** using the ▲ or ▼ keys and press **Select**.
- Select **Hide number** using the ▲ or ▼ keys and press **Select**.
- Change the status and press **Select**.

## Manage several calls

This function allows you, when enabled, to manage several calls simultaneously, provided that the service is available on the line.

### Menu > Settings > Adv. settings > Set line

- Select **Configuration** using the ▲ or ▼ keys and press **Select**.
- Select **Multi call** using the ▲ or ▼ keys and press.
- Change the status and press **Select**.

## Allow three-way communication (Intrusion)

This intrusion function allows or prohibits a second handset registered on the same base to share an ongoing conversation. If the intrusion mode is enabled, you will then be able to share a call in process with another handset.

### Menu > Settings > Adv. settings > Set line

- Select **Configuration** using the ▲ or ▼ keys and press **Select**.
- Select **Intrusion** using the ▲ or ▼ keys and press **Select**.
- Change the status by pressing **Invert**.
- Select "**Save changes ?**", press **Store**.  
The action is confirmed by the indication "**Select**".

The intrusion is not operative if the simultaneous function is enabled.

# Call management

This menu allows you to select the line on which you want to make your first outgoing call.

## Managing your calls

**Menu > Settings > Adv. settings > Selec. call line**

- The list the lines available is displayed on the screen.
- Select your line using the keys ▲ or ▼ and press **Select**.

## The list of handsets

This menu displays the list of handsets registered on the same base.

## Manage handsets

**Menu > Settings > Adv. settings > Handset list**

- The list of handsets registered on the base is displayed on the screen.
- Select the desired handset using the keys ▲ or ▼ and press **Select**.
- You have access to the actions you can perform:

**Change the handset name:** " Edit "

Change the handset name using the alphanumeric keys, Press **Clear** to delete unwanted characters. Press **Select**.

**Call the handset:** " Call "

Call the selected handset.

**Remove the handset:** " Delete "

Remove the handset's registration.

At the confirmation prompt "**Delete handset?**" press **Yes**.

**Intercept the handset:** "Interception "

Allow the handset to intercept a call.

The message "**Enter code** " is displayed. Enter the base PIN code (0000 as default), press **Select**.

Then select **On** or **Off** and press **Select**.

Setting up...

# Enjoy...


## Programming the alarm

The alarm clock function arranges for your handset to ring each day at a time you programmed.

When the alarm clock is set of, the selected ring tone rings for 60 seconds through the handset loudspeaker and a warning screen is displayed. To stop the warning, press any key on the handset.

In silent mode, phone the ring tone and the beeps are deactivated.


### Menu > Services > Alarm

- The alarm clock setting screen is displayed, press **On/Off** .
- Press the key ▼ and set the alarm clock:
  - wake-up time,
  - ring tone,
  - ringer volume.
- Select "**Save changes ?**", press **Store**.

## Program the timer

The timer function enables the handset ringer after a programmed time. You can view the time countdown in minutes on the screen.

### Menu > Services > Timer

- The timer setting screen is displayed, press **On/Off** .
- Press the key ▼ to enable or disable the timer display.
- Press the key ▼ and adjust the timer settings:
  - wake-up time,
  - ring tone,
  - ringer volume.
- Select "**Save changes ?**", press **Store** key.

# Tracing your calls...

Logs are lists of numbers or events received or sent by your telephone. Depending on your operator and the options of your contract, the following information can be accessed in the call logs:

- the date and time of the call.
- the contact's name and/or number.

Deleting or storing the numbers displayed in the call log is not allowed.

## Displaying the list of all calls

The numbers memorised in the call log are prefixed by a symbol:



: received call,




: missed call,



: outgoing call.

### Menu > Calls > All calls

- The last call is displayed with its date and time, its status (incoming, outgoing, missed), name and/or number.
- Scroll through the numbers memorised in the list using the ▲ or ▼ keys.
- Select the call you wish to view and press on **Select**.
- The following information is displayed:
  - the call status (received/sent/missed),
  - the contact's name,
  - the contact's number,
  - the call date,
  - the call time.
- Press **Back**  to return to the previous menu.

# Viewing the received or outgoing call list


Unknown calls are not included in the received call log.

## Menu > Calls > Incoming calls (or Outgoings calls)

- The last received call is then displayed.
- The other calls are displayed using the keys ▲ or ▼.
- Scroll through the numbers memorised in the list using the ▲ or ▼ keys.
- Select the call you wish to view and press on **Select**.
- Select the desired information (the call status, the contact's name and/or number, and the date/time of call) using the ▲ or ▼ keys.

The calls are displayed in the anti-chronological order (the most recent call is displayed first).

# Consulting the missed call log

The  icon is displayed if there are one or more new missed and non viewed call

Once the missed call log has been consulted, the icon disappears from all handsets.

## Menu > Calls > Missed calls

- The latest missed call is displayed.
- The other calls are displayed using the arrows.
- Scroll through the numbers memorised in the list using the ▲ or ▼ keys.
- Select the call you wish to view and press on **Select**.
- The desired information (the call status, the contact's name and/or number, and the date/time of call) using the ▲ or ▼ keys.

Tracing your calls...

# Managing the list of calls

**Menu > Calls > All calls or Incoming calls or Missed calls**

- Select the desired call and press **Select** then press **Options**.
- Select the actions you can perform:
- **Call**: call the displayed number,
- **Delete**: delete the stored number,
- **Store**: save the number in your phonebook,
- **Delete all**: delete all the numbers in the list.

## The events log

The  icon is displayed if there are one or more voice mail messages.

## Checking new events

A summary screen for the number of events that occurred in your absence is displayed:

- Number of missed calls,
- operator messages.

**Menu > Calls > Events**

- Press **Select**.
- Select **Events** then press **Select**.
- Select using the keys ▲ or ▼ **Missed** or **Voicemail** and press **Select**. The event appears on the screen.

# Environnement

Environmental protection and sustainable development is an important priority for Sunrise. Sunrise has a policy of using environmentally- friendly systems and makes environmental protection an essential part of the life-cycle of its products – from the manufacturing, to the installation, operation and disposal.

## Packaging



The logo (green point) on the packaging means that a fee is paid to an authorised national organisation to improve packaging recycling and the recycling infrastructure. Follow the local sorting regulations for this type of waste product in order to improve recycling.

## Batteries

If your product contains batteries, they must be disposed of at the designated collection points.

## The product



The crossed-out dustbin displayed on the product signifies that it belongs to the electrical and electronic equipment group. The regulations request you to carry out your own selective recycling collection.